

## Rubbish Chute Fixing Frame

1. The Fixing Frame is attached to the scaffold using two ledgers, these in turn are fixed to the standards. The two ledgers should be placed approx 300mm apart and held in place by Double Couplers, the Rubbish Chute Fixing Frame is then connected to the two ledgers, again by Double Couplers.

2. The top Rubbish Chute is connected to the short chains on the fixing frame, other chute sections are then connected to this chute.

3. A Top Hopper is placed inside the top chute section, giving access for a wheelbarrow to tip down the chute.

4. Care should be taken to ensure that debris can not escape down the sides, of the Top Hopper section and fall on workers below.

